



DETAILS OF THE MAIN STATOR AND MAIN TERMINAL CONNECTIONS ARE SHOWN ON SEPARATE WIRING DIAGRAM

* INLINE CONNECTORS ARE FITTED ON FRAME 4 AND ABOVE

EXCITATION SWITCH (when fitted) REMOVE LINK ACROSS K1 & K2

HAND TRIMMER (when fitted) REMOVE LINK ACROSS 1 & 2 THE USE OF TWO CORE INSULATED SCREENED CABLE IS RECOMMENDED. CONNECT SCREEN TO AVR TERMINAL 2 ONLY.

DROOP C/I (when fitted) FOR C/T POSITION SEE CONNECTION DIAGRAM

BASE DIAGRAM

CERTIFIED PRINT (ONLY IF SIGNED)		FRAME ---	OTHER FEATURES
BY		CONTROL SERIES MX321	
DATE		POLES	
DRAWN		No. OF ENDS ---	
CH'D		SENSING 3 PHASE	
APP'D			ISSUE B
SHEET 1 OF 1 SHEETS			